

# PILASTER CAPITALS



Pilaster Capital installation

**Note:** the width (W) and projection (P) measurements are given at the point on the pilaster above the bulnose, these measurements correspond with the pilaster shaft width and projection required by the capital



**PC-003**  
H. 6 1/2"  
W. 3 1/4"  
P. 1"



**PC-004**  
H. 6 3/4"  
W. 3 1/4"  
P. 3/4"



**PC-005**  
H. 7"  
W. 6"  
P. 1 1/2"



**PC-006**  
H. 4 1/2"  
W. 2 5/8"  
P. 5/8"



**PC-007**  
H. 6 5/8"  
W. 5"  
P. 1 3/4"

Scale - 3" = 1' - 0"



**PC-001**  
H. 10 1/4"  
W. 6"  
P. 2"



**PC-002**  
H. 8"  
W. 6 1/8"  
P. 1 1/2"

Scale - 1 1/2" = 1' - 0"



**FELBER**  
ORNAMENTAL  
PLASTERING CORP.

PO BOX 57, 1000 WEST WASHINGTON STREET  
NORRISTOWN, PENNSYLVANIA 19404

FAX: 610-275-6636 1-800-392-6896 WEB: www.felber.net